

**RECOMMENDED INSTALLATION HEIGHT
FOR EACH VAN MODEL**



SECURITY LOCK FOR BOX VANS.

WARNINGS

Since the doors of different setups vary based on specific needs, it is not possible to define a universal height. However, it is recommended to install the security system above the external handles of the doors, at a height easily accessible to the operator standing on the ground, thus not too high.



Please take into account the internal distance between the locking shafts of the doors. The drilling template indicates the minimum distances that allow installation with exposed shafts (minimum internal distance 190 mm) or recessed shafts inside the doors (minimum internal distance 150 mm). Before permanently positioning the template, check for possible interferences with external or internal elements of the doors and the vehicle's original locking systems.

